


GRANITE WIRE DIAGRAM

NOTE: Take care to make sure the live AC line and the neutral AC line into the controller are installed in the proper positions. Reversing these two lines will result in poor operation and/or controller damage!



Smithy Co. copyright 1999
Server "P"/granite/granite wire/dew/09-14-99